

Quick Installation Guide

AC600 Wireless Dual Band USB Adapter

MODEL NO. Archer T2U


7106505282 REV2.0.1



For more information, please visit our website: <http://www.tp-link.com>

1 Connect to a Computer

Insert the adapter into a USB port on your computer directly.




Note:

1. In Windows XP, a Found New Hardware Wizard window will appear when the adapter is detected. Please click **Cancel**.
2. In Windows 8.1, the adapter is able to search for Wi-Fi networks after being inserted, but it will not function properly until you install the driver and utility below.

2 Install Driver and Utility


You can also download the driver and utility at www.tp-link.com

A: Insert the CD and click **Run Autorun.exe** from the pop-up Autoplay window.



Note: In some operating systems, the CD screen will pop up automatically. Otherwise, run the CD manually.


B: Select Archer T2U and click **Install Driver and Utility**, then follow the InstallShield Wizard to complete the installation.



3 Join a Wireless Network

Option 1: Via TP-LINK Utility

Select your preferred Wi-Fi network from the pop-up utility window and click **Connect**. The symbol  indicates a successful connection.



Option 2: Via Windows Wireless Utility

Click  (Network icon) on the system tray, select your Wi-Fi network, and click **Connect**.

Note: In Windows XP, you need to close the TP-LINK Utility before using the Windows Wireless Utility.